# **WINDSOR**

#### Axcess Total Floor Care









01) Remove and clean the brush once a week.

02) Replace the pads on the burnisher when they become ¼ inch thick.

03) Lift up the tab and remove the vacuum bag to replace.



86374530







04) Replace the secondary filter quarterly.

05) To remove a clog from the hose, press the orange flap to remove the hose and clean with a broom handle.

Bold Innovation, Expert Results. Bold Innovation, Expert Re

### **WINDSOR**

# **AXCESS TOTAL FLOOR CARE**










01) Inspect brush for wear using a credit card and replace if necessary. **OPERATION** 

02) Make sure all three prongs are on the body of the cord and plug into an outlet. IF ONE OF THE PRONGS IS MISSING, NOTIFY YOUR SUPERVISOR.

03) Lift orange flap and clear out any clogs.



86374530







07) To burnish, replace the 06) Starting at the highest 04) Turn the vacuum on. setting, adjust brush height vacuum head with the to the highest setting. setting by setting until the burnishing head and a orange light turns off. burnishing pad.

### **WINDSOR**

### **AXCESS TOTAL FLOOR CARE**









08) On the burnishing head, use red or green pads for standard use and yellow pads for restoring gloss.

09) Unplug the cord from the wall.

strain relief when wrapping the cord.









11) Wrap the cord for storage starting from the base. Wrapping the cord properly will help prevent cord failure.